

clearwater



Instructions for Chic, Cottage Slipper 1550, Dynasty, Espania, Italiano, Italiano Plus & Orient Bath

Please read carefully prior to commencing any work.

Any installation should only be carried out by a qualified tradesman with knowledge of the Statutory Regulations and plumbing requirements for your area.

HANDLING

Please note that this product has been through our rigid quality control procedures which include a thorough visual inspection under bright lights water testing etc. Please unwrap the bath and check it carefully to ensure it has not been damaged in handling or transport which is beyond our control.

Do not remove the old fixture before you unpack and inspect the new unit. Upon receipt, check for shortages. Report any shortages immediately. Store the bath and wall surrounds in a safe place until you begin installation to avoid damage.

Claims regarding cracks and/or face damage must be reported within 24 hours of receipt of the product. No such claims will be recognised after installation as this is classed as acceptance of the product.

The bath should not be exposed to direct flame or abnormal heat. Once installed it is good practice to cover the entire bath with a soft protective cloth until other trades have completed their work.

Assembly Instructions

1. To ease alignment and fitting of the plinth, it is recommended that the bath be turned upside down.
2. Place a bead of silicone sealant onto the bath where the plinth sits.
3. Align the holes and push the bolts through.
4. Tighten until plinth is secure. (Do not over tighten.)
5. Turn bath over and position it ready to be plumbed in.

Further Advice

- When plumbing in your both it is very important to seal all holes that water travels through such as waste and overflow holes.



CAUTION: Risk of product damage.

- It is advisable always to run in some cold water before turning on the hot tap
- Do not use abrasive cleaners.
- Wipe your bath with a soft cloth after each use to prevent a build-up of soap and residue.
- Avoid cleaning products that contain acetone, ethyl alcohol, amyl or ethyl acetate, sodium hypochlorite, toluene, or phenol. These products can damage the finish
- Extreme heat such as that generated by cigarettes or portable heaters can damage Acrylic surfaces. Do not use such items near your bath.
- In the event of slight scratches in the bath surface, a mild abrasive, similar to metal polish, can be used to polish these out.

FOR TECHNICAL ADVICE/ SPARE PARTS PLEASE CONTACT OUR CUSTOMER SERVICES DEPARTMENT
Tel. 519-690-0009 Fax. 519-690-0008

TO THE INSTALLER

Please leave the instruction leaflet for the customer

Clearwater Collection Ltd