

## Instructions for Deva, Eros, Jupiter, Luna & Soho

Please read carefully prior to commencing any work.

Any installation should only be carried out by a qualified tradesman with knowledge of the Statutory Regulations and plumbing requirements for your area.

### HANDLING

Please note that this product has been through our rigid quality control procedures which include a thorough visual inspection under bright lights water testing etc. Please unwrap the bath and check it carefully to ensure it has not been damaged in handling or transport which is beyond our control.

Do not remove the old fixture before you unpack and inspect the new unit.  
Upon receipt, check for shortages. Report any shortages immediately.  
Store the bath and wall surrounds in a safe place until you begin installation to avoid damage.

**Claims regarding cracks and/or face damage must be reported within 24 hours of receipt of the product. No such claims will be recognised after installation as this is classed as acceptance of the product.**

The bath should not be exposed to direct flame or abnormal heat. Once installed it is good practice to cover the entire bath with a soft protective cloth until other trades have completed their work.

### Assembly Instructions

1. Place the plinth in the desired position.
2. For wood plinths place a bead of silicone sealant on the top inside edge of the plinth where it meets the bath to prevent water damage.
3. For metal plinths place a bead of silicone on the top of the frame where it meets the bath to secure the bath to the plinth
4. Simply place the bath onto the plinth ready for plumbing

### Further Advice

- **When plumbing in your both it is very important to seal all holes that water travels through such as waste and overflow holes.**
- An exposed waste is not compatible with the Soho or Eros bath
- Holes can be drilled in the wood plinths for fitting of external waste pipes, but these must be sealed to prevent water damage.



### **CAUTION: Risk of product damage.**

- It is advisable always to run in some cold water before turning on the hot tap
- Do not use abrasive cleaners.
- Wipe your bath with a soft cloth after each use to prevent a build-up of soap and residue.
- Avoid cleaning products that contain acetone, ethyl alcohol, amyl or ethyl acetate, sodium hypochlorite, toluene, or phenol. These products can damage the finish
- Extreme heat such as that generated by cigarettes or portable heaters can damage Acrylic surfaces. Do not use such items near your bath.
- In the event of slight scratches in the bath surface, a mild abrasive, similar to metal polish, can be used to polish these out.

**FOR TECHNICAL ADVICE/ SPARE PARTS PLEASE CONTACT OUR CUSTOMER SERVICES DEPARTMENT**  
Tel. 519-690-0009 Fax. 519-690-0008

**TO THE INSTALLER**  
Please leave the instruction leaflet for the customer

Clearwater Collection Ltd